



Hollow Wall Drive Anchors

Product Description

The Hollow Wall Drive Anchor is a toggle anchor made entirely of steel. It is vibration resistant. Sizes available are 1/8" Short Drive to 1/8" Special Long Drive. For a faster result and easier way to install, try the NEW Triple Grip from Cobra.



Features & Benefits

- ▶ For drywall 3/8", 1/2" and 5/8", plaster, block and paneling
- ▶ Sizes available: 1/8" Short Drive to 1/8" Special Long Drive

Perfect for:



Bathroom cabinet, curtain rod, towel bars etc...

Packaging:



Product sizes & Materials

Plated Steel

- 1/8" SD
- 1/8" LD
- 1/8" SLD
- 1/8" LDHH C

Suitable Base Materials

- ▶ Drywall 3/8 – wallboard 10 mm
- ▶ Drywall 1/2 – wallboard 13 mm
- ▶ Drywall 5/8 – wallboard 16 mm
- ▶ Plaster
- ▶ Hollow Block
- ▶ Paneling





Load Capacities

Hollow Wall Drive Anchors

Material	Size	Material	Head Styles	Bolt Dia.	Grip Range	PULL MAX lb	PULL SAFE lb	SHEAR MAX lb	SHEAR SAFE lb	PULL MAX kg	PULL SAFE kg	SHEAR MAX kg	SHEAR SAFE kg
3/8 Drywall Wallboard 10 mm	1/8" SD	Plated Steel	Pan	6-32	1/8" - 1/2 "	80	40	110	55	36	18	50	25
	1/8" SLD	Plated Steel	Pan	6-32	1/8" - 1 3/16"	80	40	110	55	36	18	50	25
	1/8" LDHH	Plated Steel	Hex	6-32	1/8" - 1 3/16"	80	40	110	55	36	18	50	25

Material	Size	Material	Head Styles	Bolt Dia.	Grip Range	PULL MAX lb	PULL SAFE lb	SHEAR MAX lb	SHEAR SAFE lb	PULL MAX kg	PULL SAFE kg	SHEAR MAX kg	SHEAR SAFE kg
1/2 Drywall Wallboard 13 mm	1/8" SD	Plated Steel	Pan	6-32	1/8" - 1/2 "	150	75	170	85	68	34	77	39
	1/8" SLD	Plated Steel	Pan	6-32	1/8" - 1 3/16"	150	75	170	85	68	34	77	39
	1/8" LDHH	Plated Steel	Hex	6-32	1/8" - 1 3/16"	150	75	170	85	68	34	77	39

Material	Size	Material	Head Styles	Bolt Dia.	Grip Range	PULL MAX lb	PULL SAFE lb	SHEAR MAX lb	SHEAR SAFE lb	PULL MAX kg	PULL SAFE kg	SHEAR MAX kg	SHEAR SAFE kg
5/8 Drywall Wallboard 16 mm	1/8" LD	Plated Steel	Pan	6-32	5/8" - 7/8 "	160	80	195	98	73	37	88	44
	1/8" SLD	Plated Steel	Pan	6-32	1/8" - 1 3/16"	160	80	195	98	73	37	88	44
	1/8" LDHH	Plated Steel	Hex	6-32	1/8" - 1 3/16"	160	80	195	98	73	37	88	44

Tools required



Installation instructions

- Using a hammer, tap the Hollow Wall Drive anchor into wall until flush with surface.
- Using a screwdriver, turn the screw clockwise until you feel resistance. This activates the wings behind the drywall.
- Unscrew the screw from the Hollow Wall Drive Anchor.
- Insert the screw through the object you need to a, and screw clockwise into the anchor until there is a strong resistance.

